
MSD® 384-Well MULTI-ARRAY® Total MEK1/2 Assay

The following assay protocol has been optimized for analysis of total MEK1/2 in whole cell lysate.

		<u>Storage</u>
M	laterials Included	
	MSD Read Buffer T (with surfactant), 4X	RT
	MSD Blocker A	RT
	MULTI-SPOT® 384-well 4 Spot Total MEK-1/2 Plates	2-8°C
	MSD SULFO-TAG [™] Anti-Total MEK-1 Antibody (50X)	2-8°C
	MSD SULFO-TAG Anti-Total MEK-2 Antibody (50X)	2-8°C
	MSD Tris Wash Buffer (10X)	2-8°C
	MSD Tris Lysis Buffer	2-8°C
	Phosphatase Inhibitor I (100X)	2-8°C
	Phosphatase Inhibitor II (100X)	2-8°C
	MSD Blocker D-M (2%)	≤-10°C ¹
	MSD Blocker D-R (10%)	≤-10°C ¹
	Protease Inhibitor Solution (50X)	≤-10°C
	PMSF in DMSO (250X)	≤-10°C



The SECTOR® Imager data file will identify spots according to their well location, not by the coated capture antibody name.

FOR RESEARCH USE ONLY.
NOT FOR USE IN DIAGNOSTIC OR THERAPEUTIC PROCEDURES.



¹ Blockers D-M and D-R can tolerate up to 5 freeze-thaw cycles. Alternatively, an aliquot of blockers D-M and D-R can be stored at 2-8°C for up to 1 month.

Notes:

Other Materials & Equipment (not supplied)

- Deionized water for diluting Wash Buffer and Read Buffer
- □ One 1 L bottle
- □ Two 50 mL tubes
- □ One 15 mL tube
- □ Adhesive plate seals
- □ Microtiter plate shaker
- □ Various microcentrifuge tubes for making serial dilutions of lysates (if desired)
- ☐ Automated plate washer or other efficient multi-channel pipetting equipment for washing 384-well plates
- Appropriate liquid handling equipment for desired throughput that must accurately dispense 10,20, and 35 μL into a 384-well micro plate
- □ Positive and negative control lysates.

Read the entire detailed instructions before beginning work.

Protocol at a Glance

The following protocol describes the most conservative approach toward achieving highly sensitive results using MSD technology to quantify phosphoproteins. The protocol can be completed in approximately 5 ½ hours or overnight if each reagent is prepared during the preceding incubation. All reagents with the exception of diluted lysates can also be prepared ahead of time. This lengthens the overall time required for the assay but frees up time during incubation steps.

Once desired results are achieved, the protocol can be streamlined to eliminate multiple incubation and wash steps to increase throughput.

- 1. Add blocking solution, incubate 1 hour, wash.
- 2. Add samples or lysate, incubate 2 hours at room temperature, wash.
- 3. Add Detection Antibody, incubate 2 hours, wash.
- 4. Add Read Buffer and analyze plate.

Detailed Instructions

Prepare a stock of 1X Tris Wash Buffer:

- a) The stock of 1X Tris Wash Buffer will be used throughout the assay to make other reagents as well as wash plates.
 Approximately 1 L per plate is required—more if using an automatic plate washer.
- b) In a 1 L bottle combine:
 - □ 100 mL 10X Tris Wash Buffer
 - ☐ 900 mL deionized water



A larger amount of Tris Wash Buffer may be prepared at once and stored at room temperature for later use.

Notes:

Prepare MSD Blocking Solution-A:

- a) Prepare 20 mL per plate.
- b) In a 50 mL tube combine:
 - □ 20 mL 1X Tris Wash Buffer
 - □ 600 mg MSD Blocker A (30 mg/mL or 3%)

Solutions containing MSD Blocker A should be kept at 4°C and discarded after 14 days.

Prepare Antibody Dilution Buffer:

- a) Prepare 8 mL per plate.
- b) In a 15 mL tube combine:
 - ☐ 2.67 mL MSD Blocking Solution-A
 - ☐ 4.85 mL 1X Tris Wash Buffer
 - 400 μL 2% MSD Blocker D-M
 - 80 μL 10% MSD Blocker D-R

Begin with an MSD MULTI-SPOT Total MEK-1/2 Plate. No pre-treatment is necessary.

STEP 1 Add 35 µL/well of MSD Blocking Solution-A.

Incubate with shaking at room temperature for 1 hour. Prepare Complete Tris Lysis Buffer, and prepare samples or dilute cell lysates during this time.

Prepare Complete Tris Lysis Buffer:

- a) To 10 mL of Tris Lysis Buffer, add the following:
 - □ 100 μL Phosphatase Inhibitor I (100X stock)
 - □ 100 μL Phosphatase Inhibitor II (100X stock)
 - 200 μL Protease Inhibitor Solution (50X stock)
 - □ 40 µL PMSF in DMSO (250X stock)
- b) Mix thoroughly for 5 minutes at room temperature (preferably on a rotator).
- c) Keep Complete Tris Lysis Buffer on ice until use.

overnight at 4°C.

Plates may also be blocked

Complete Tris Lysis Buffer should be made each day of experimentation.

The complete Tris Lysis Buffer should be ice cold before use.

Prepare samples or positive and negative cell lysates:

(Note: Recommendations for cell lysate handling are provided, however, the suggested concentrations listed below may need to be adjusted depending upon specific samples tested.)

a) Thaw cell lysate samples on ice and dilute immediately before use. Keep on ice during all manipulations and discard all remaining thawed unused material.



b) Dilute MEK positive and negative cell lysates in Complete Tris Lysis Buffer to a final concentration of $0.5 \mu g/\mu L$. This will deliver 5 µg/well in 10 µL. A dilution series may also be prepared if desired.

Wash plates four times with Wash Buffer.

Notes:

Shaking a 384-well MSD MULTI-ARRAY or MULTI-SPOT plate accelerates capture at the working electrode.

STEP 2 Dispense 10 µL/well of samples or diluted lysates.

> Incubate with shaking for 2 hours at room temperature. Prepare Detection Antibody Cocktail during this time.

Prepare Detection Antibody:

In a 15 mL tube combine (per plate):

- a. 7.68 mL cold Antibody Dilution Buffer
- b. 160 µL 50X Anti-Total MEK-1 Antibody (Final concentration: 1X)
- c. 160 µL 50X Anti-Total MEK-2 Antibody (Final concentration: 1X)

Wash plates four times with Wash Buffer.

STEP 3 Add 10 µL/well of Detection Antibody.

> Incubate with shaking at room temperature for 2 hours. Prepare Read Buffer during this time.

Dilute Read Buffer:

In a 50 mL tube, combine (per plate):

5 mL 4X Read Buffer T

□ 15 mL deionized water

Wash plates four times with Wash Buffer.

STFP 4 Add 35 µL/well of diluted Read Buffer T (with surfactant).

Analyze with SECTOR Imager instrument.

Diluted Read Buffer may be kept in a tightly sealed container at room temperature for later use.

Bubbles in the Read Buffer will interfere with reliable imaging of the plate if carried into the wells.

Plates can be imaged immediately following the addition of read buffer. Most biological interactions tolerate incubation in Read Buffer, however each unique assay should be tested for stability in read buffer before being left to sit for extended periods.

Meso Scale Discovery, Meso Scale Diagnostics, www.mesoscale.com, MSD, MSD (design), Discovery Workbench, Quickplex, Multi-Array, Multi-Spot, Sulfo-Tag and Sector are trademarks of Meso Scale Diagnostics, LLC.

© 2010 Meso Scale Discovery a division of Meso Scale Diagnostics, LLC. All rights reserved.

